

Technical Data Sheet

Universal Degreaser & Cleaner

A water-based detergent that is colour fast, fabric safe and removes tough stains quickly and effectively from many surfaces.

Perfect for preparing surfaces before painting, also great for removing dried water-based paint, paint overspray, tape residue, glue and adhesive, wax, food & drink stains, bird droppings, smoke damage, tree sap, grease & oil, marker & crayon, pet stains, brake dust, fireplace soot, oxidation, lipstick, scuff marks, blood stains, sun tan oil, tar, chewing gum, soap scum, shoe polish, & more.

- Concentrated cleaner, degreaser & stain remover
- Removes tough stains fast
- Effective against grease & oil
- Ideal for cleaning before painting

SUITABLE SURFACES – Tiles, grout, baths, sinks, showers, tools & equipment, machinery, driveways, BBQs, & ovens. Always test on an inconspicuous area first. This product may mark metal and glass; ensure to cover and protect glass or metal surfaces during cleaning of adjacent areas. Do not use on varnished surfaces or leather.

APPLICATION – Always test on an inconspicuous area first. Cover areas not to be cleaned. Never mix with other chemicals. Always wear the correct personal protective equipment; chemical resistant gloves, safety glasses with side shields and protective clothing in accordance with the instructions stated on the packaging. A separate Safety Data Sheet is available on our website or by contacting us direct. Apply directly on to the surface to be cleaned and allow to penetrate briefly. Wipe off with a clean cloth or towel. If using prior to painting, ensure any residue is thoroughly rinsed off. For older, more difficult jobs, apply a generous amount of cleaner and allow to stand for a few minutes before wiping dry. For extremely tough jobs, such as the removal of old dried paint, scrub with a brush or scouring pad and wash off with a wet rag. For engine cleaning, use on a cold, dry engine.

CLEANUP – Do not empty into drains or watercourses.

UK LIMITED WARRANTY by Zinsser (UK) Ltd: The contents of this container are warranted to be free of defects for two years from the date of manufacture. This limited warranty is limited to replacement of refunded value of product used when supported by proof of purchase. If you wish to make a warranty claim, please contact Zinsser (UK) Ltd. If you are a consumer, this warranty does not affect your statutory rights.